

SECTION 4.0 Annex A**MAINTENANCE TASKS AND AUTHORITIES REQUIRED**

MAINTENANCE TASK	AUTHORITY REQUIRED		REMARKS
	Private Operations	Hire & Reward [Flying Training]	
Post Assembly	L1	L2	
Pre-Flight	Pilot	Pilot	
Daily	L1	L1	
Scheduled	L1	L2	
Repairs	L1	L2	
Modifications	L 1	L2	Refer to Section 3.5 of RA-Aus Technical Manual
Airworthiness Notice	L1	L2	Plus what is in the Notice
Heavy Landing	L1	L2	
All Component Overhaul	L1	L2	
All Component Replacement	L1	L2	
Engine Installation	L1	L2	
Welded Repairs	L1	L2*	*CASA Welding authority needed for hire & reward, or on approval from the Technical Manager

An aircraft owner is free to ask a Level 2 to carry out, check or advise on any maintenance of their aircraft.